

Overhead Lifting Solutions Photo Gallery

Flat Board Process Systems



Free Standing Workstation Bridge Crane



Free Standing floor supported systems do not put stress on the building's overhead structure. Installation is usually more straight forward, and these cranes are also easier to relocate in the future. Free Standing systems require a reinforced concrete floor of at least 6 inches.

Free Standing Workstation Jib Crane



Free standing work station jib cranes can be bolted directly to your existing floor without adding special foundations. Installation and adjustment are easy with our eccentric cam followers.

Easy Arm w/ Rotation Device

