



## **Pop-Up Product Stops**

Pin & Blade Stops - Pneumatically or manually operated pin or blade that pops up between rollers to accumulate product.

**Pop-Up Blade Stop -** Used to stop products in the conveying line. Mounted to underside of conveyor, pneumatic cylinder raises blade.










PNEUMATIC POP-UP BLADE STOP

**Rotating Blade Stop -** Allows product placement within a lower mechanical profile.

Pin Stop - Mounted to underside of conveyor. Pneumatic cylinder raises pins. Typically utilize on round product.

Pin & Blade Stops - Pneumatically or manually operated pin, blade and roller stop that pops up between rollers in order to accumulate product.

Manual Pop-Up Blade Stop - Used to stop products in the conveying line. Mounted to underside of the conveyor. Side handle for manually raising blade. Load capacity is rated for maximum accumulated back pressure of 75#.







Pin Stop - Mounted to underside of conveyor. Pneumatic cylinder raises pins. Typically utilized on round product.



PIN STOP PIN AND BLADE STOPS







PNEUMATIC POP-UP BLADE STOP